


User Manual Coocase Adjustable Backrest

The design of this product is to adjust the backrest for your riding position. Follow the steps below to make the adjustment during use. Remember the scale number so you can always set the backrest to the same position.

The adjustable backrest's TUBE includes three buttons as shown in the diagram : Button B1 is for extending or retracting TUBE A and B.

Buttons B2 and B3 should be pressed together to adjust the four angles of the backrest.




Adjustment Instruction:

1. TYPE A Adjustable Range Instructions:

Adjustable Backrest Model:	AB45L	SOAB45L	AB55L/65L
Extension Range In CM:	26.5CM-42.5CM	36.5CM-57.5CM	32.5CM-51.5CM


1. First, press and hold Button B1 to pull out TUBE A and TUBE B to their maximum length.
2. Push TUBE B back to desired position, TUBE A has markings 1-7 or 1-10 with corresponding holes. Determine the final suitable scale number for yourself.
3. Next time, just adjust to that number.




2. TYPE B Adjustable Range Instructions:

Adjustable Backrest Model:	AB45L	SOAB45L	AB55L/65L
Extension Range In CM:	8CM-26.5CM	10CM-36.5CM	9CM-32.5CM

1. Press and hold Button B1 pull out TUBE A and TUBE B partially ,do not pull them out completely, push TUBE A back to its original position.
2. TUBE B has engravings 1-7 or 1-10. press and hold Button B1 with your hand on the edge of TUBE A (to ensure the TUBE A not pull out), and pull TUBE B back and forth to test each hole position on the scale of the TUBE B to determine the final scale number that suits you.
3. Remember the suitable number. Next time, adjust to that number.



4. Press Button B2 and B3 at the same time, swing the backrest back and forth to adjust the angle that fits your back.



IMPORTANT SAFETY WARNING:

1. Always ensure that the backrest is adjusted to the desired position before riding (figure 1).



2. Do not adjust the backrest while the vehicle is in motion.

3. When not in use, ensure that the backrest is pulled back in original position (figure 2).



4. Do not press on the backrest when getting on or off the bike.



5. Be careful of the extended backrest when getting on and off the bike.

